

Statement of Volatility

Introduction

This document describes volatile and non-volatile on the specified product(s). Customers can use this document to comply with security requirements and equipment handling procedures.

Contact Information

If you have any questions after you review the information in this documentation, please contact your local Prostat Authorized Reseller, distributor, or call Prostat corporate headquarters (toll-free inside the U.S. and Canada only) at 1-855-782-8421, or from outside the U.S. at +1-630-238-8883.

Products

This document contains procedures for the following product:

- Prostat CPM-766 Charged Plate Monitor

Description of Device

Microcontroller

It contains operating code for the instrument and calibration constants in 128 kB non-volatile flash memory.

Clearing procedure:

To erase all the stored measurements at once from the meter's memory, perform the following steps:

- Tap in the Settings icon at the bottom of the screen.
- Tap on Memory.
- Tap on Clear all Stored Measurements.
- Confirm when prompted.

Sanitize Instrument Data

The only way to sanitize data from these instrument is to physically remove the non-volatile chips listed above. It is not recommended that the user removes the chip(s) from the instrument and should be handled by a Prostat Authorized Calibration Lab.